



Drive Through Foam Wall Berm Setup

- Once the berm has been taken out of its storage bag, **lay the berm out flat** and fold in the sides. At this point the berm should be pulled out to its actual size.



- Lay the **foam alongside each of the pockets** that are welded on. The pockets surround the outer perimeter of the berm approximately 2 ft apart. The memory foam is for the part of the berm that will be driven over and the other foam pieces are for the sides.

- **Slide the foam into the pockets** from bottom to top with the berm sides folded in, and pockets facing up. The exposed part of the foam not in the pocket should be placed beneath the berm.



Options:

- Consider the use of drive over mats or a ground liner to extend the life of your berm.
- Consider tire treads to extend the life and protect the berm.

